

Anexo VI: Deleting GS separator

To remove the GS separators, scan the code below.

Step 1. Scan code



Deleting GS separator